


SU: Sunday, MO: Monday, TU: Tuesday, WE: Wednesday, TH: Thursday, FR: Friday, SA: Saturday
(Changeover between 12-hour and 24-hour formats) in regular timekeeping mode.
with every push of Δ , the display is switched between 12-hour and 24-hour formats.

If the daily alarm is set, the buzzer sounds for 20 seconds at the preset time every day until cleared. To stop the buzzer, press the button. If the time signal is set, the watch sounds every hour on the hour.
(Sound demonstration) Press and hold the button in alarm mode to sound the buzzer.



The diagram illustrates the states of a digital alarm clock through a sequence of four states, each represented by a rounded rectangle containing a digital display showing '8:35'.

- State 1:** The alarm-on-mark and time-signal-on-mark appear. Below the display, it says 'The daily alarm and time signal sound.' Pressing 'A' leads to State 2.
- State 2:** The alarm-on-mark and time-signal-on-mark disappear. Below the display, it says 'The daily alarm and time signal do not sound.' Pressing 'A' leads to State 3.
- State 3:** The alarm-on-mark only appears. Below the display, it says 'The daily alarm only sounds.' Pressing 'A' leads to State 4.
- State 4:** The time-signal-on-mark only appears. Below the display, it says 'The time signal only sounds.' Pressing 'B' leads back to State 1.

[Regular timekeeping] [Second adjusting] [Hour setting] [Minute setting]

Press **C** three times to change regular timekeeping mode to time-alphabet setting mode.

Press **5** to adjust second.

Press **1** to move to the hour setting. Press **+** to increase the number.


Press **1** to move to the minute setting. Press **+** to increase the number.

Accuracy at normal temperature: ± 30 seconds a month
 Display capacity:
 • Regular timekeeping mode
 • Hour, minute, second, alarm, date and day
 • Calendar system: Auto-calendar set at 28 days for February
 • Only alarm mode
 • Hourly time signal function
 • Watchdog mode
 • Measuring capacity: 500 micro 50.99 seconds
 • Measuring unit: 1/1000 s
 • Measuring mode: Normal time, next, split time and 1st-2nd place times
 Battery:
 • One lithium battery (type CR-2016 – see model 1271 (BR-2020 – Model 1271 only)
 • Approx. 7 years operation on type CR-2016 (except Model 1271) / 10 years on type BR-2020 (except Model 1271 only). [assuming alarm operation for 20 sec. and time light operation for 1 sec.] daily]
NOTE: There is NO way any user components can be damaged or malfunction due to the use of this device. No combining information appears on the display if it means the sequence was incorrect. Please read the manual and try again.

A signal confirms start/stop operation.
(Working range) The stopwatch display is limited to 55 minutes 59.99 seconds, for longer times reset and start again.



IMPORTANT: Setting sequence **MUST BE FOLLOWED** when making any new setting



- Correction of any digit, if not required, can be skipped by pressing the **(1)** button repeatedly.
- If you do not operate any button for a few minutes while a selection is flashing, the flashing stops and the watch goes back to the regular timekeeping mode automatically.

